

[Acqua A5, Arietta G25] Auto login

A volte si preferisce accedere da terminale evitando di inserire il nome utente e la password.

Editare il file `/etc/inittab` e verso la fine del file troverete questa riga di codice:

```
T0:2345:respawn:/sbin/getty -L ttyS0 115200 vt100
```

Commentare la riga e aggiungere quella riportata successivamente:

```
#T0:2345:respawn:/sbin/getty -L ttyS0 115200 vt100  
T0:2345:respawn:/bin/login -f root ttyS0 </dev/ttyS0 >/dev/ttyS0 2>&1
```

Al prossimo riavvio non ci sarà bisogno di inserire il nome utente e la password:

```
[ ok ] Configuring network interfaces...done.  
[....] Cleaning up temporary files...IPv6: ADDRCONF(NETDEV_UP): eth0: link is not ready. ok  
  
INIT: Entering runlevel: 2  
[info] Using makefile-style concurrent boot in runlevel 2.  
GSM SMS deamon not yet configured. Edit /etc/default/gsm-utils first.  
[ ok ] Starting OpenBSD Secure Shell server: sshd.  
Last login: Mon Jan  1 00:15:07 UTC 2007 on ttyS0  
Linux acqua 3.10.0 #4 Mon Dec 15 17:16:39 CET 2014 armv7l  
  
The programs included with the Debian GNU/Linux system are free software;  
the exact distribution terms for each program are described in the  
individual files in /usr/share/doc/*/copyright.  
  
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent  
permitted by applicable law.  
root@acqua:~#
```